



PETE'S
Party & Tent
RENTAL

315 Lorne Street, Sudbury, ON P3C 4R1

Phone: 705-673-7383 www.petesrentall.ca

MINI
GOLF
#1 GAME



ASSEMBLY/SETUP INSTRUCTIONS

1. Select a level area to operate the game with plenty of room to allow for a line to form leaving a safe distance between player and spectators.
2. To assemble take the belt from the motor and stretch to the middle back wheel of the windmill. Make sure it is sitting in the groove of both wheels.
3. Adjust the 2 windmill arms so that they are opposite each other.
4. Plug in power supply adapter.

*****FOR SAFETY'S SAKE*****

1. Be sure there is plenty of clearance between the player and the spectators.
2. Keep spectator's clear from the sides and back of the setup to prevent from being struck by deflected or errant throws.
3. Use only the golf balls that come with the game.

Items Include:

- Main unit, 2 balls, 1 putter, power supply (12 volt DC with 2.1 mm plugin adapter)